

Hytera RoIP

- User name - your ID
- Password - your BM's hotspot password

The screenshot shows the 'RoIP Settings' page in a web interface. The breadcrumb trail is 'Broadband > RoIP Settings > RoIP Settings'. The left sidebar has a menu with 'RoIP Settings' selected. The main content area has a 'Settings' section with a 'RoIP Network' toggle set to 'On'. Below this are input fields for 'User Name' (2357109) and 'Password' (Hotspot-Pass). There is also a 'Protection Time for BB-to-NB Switch(s)' dropdown set to '1'. At the bottom, there is a 'RoIP Server' section with an 'Add' button.

- MNI - set what do you use in TMO configuration, most probably its 901 9999
- Server - core.tetrapack.online (domain name, not IP! that's strict)
- Port - use standard 3003

This screenshot shows the 'RoIP Server' section of the settings page. It includes an 'Add', 'Delete', and 'Empty' button bar above a table. The table has columns for 'No.', 'MCC', 'MNC', 'Server Address', and 'Server Port'. One server is listed with MCC 901, MNC 9999, and Server Address core.tetrapack.online. The 'Protection Time for BB-to-NB Switch(s)' dropdown is also visible at the top of this section.

No.	MCC	MNC	Server Address	Server Port
1	901	9999	core.tetrapack.online	3003

Revision #12

Created 23 September 2024 14:22:35 by 2E0YCA Elliott

Updated 21 May 2025 18:50:58 by R3ABM