

TetraPack

FUNK.TAG 2024


Artöm DL5ABM

TetraPack.online


Summary

- Introduced at HamRadio 2023 in Friedrichshafen
- “multiple vendor’s TETRA TMO in one PACKage”
- The same goals like BrandMeister Network has:
- Support of different hardware
- Widely-available talk-groups
- Most of services and user-experience for TETRA TMO
- In most cases - connect network controllers (SwMI) instead of base stations
- Closed integration to BrandMeister Network:
- Seamless exchange of group calls, individual calls, SMS
- Almost all services available in BrandMeister Network: APRS, SMS services, etc.

Core system architecture



Network topology



Roles of components

- **TetraPack Core**

- User registration / TG affiliations
- Calls and data switching
- Radio access connectivity
- Acts as a transit switching center

- **Registry**

- HLR/VLR
- Call routing

- **BrandMeister Core**

- TETRA <--> DMR individual and group calls, SMS bridging
- GPS and SMS apps handling (APRS, DAPNET, MQTT, HTTP API)
- Any TG > 90 and registered personal IDs seamlessly available across both networks

- **Asterisk PBX / chan_transit.so**

- Individual and phone calls bridging, IVR apps
- SMS apps and bridging

- **SVXLink / DockLogic.so**

- TETRA-DMO group calls bridging (+ passing of ISSI)

SVXLink

DockLogic.so

- **DockLogic.so – our own SVXLink Logic module, implements TetraPack’s Dock IPC protocol (should run on the same host as TetraPack Core)**
 - Works on top of pure DL1HRC’s SVXLink / tetra-contrib
 - Requires nodes to use the same CALLSIGN in [ReflectorLogic] and [TetraLogic] to make our bridges pass talker’s ISSI correctly
- **Patches applied to SVXReflector and ReflectorLogic at DL1HRC’s GitHub.com**
 - Pass originating ISSI over SVXReflector to TetraLogic / DockLogic
 - Reflector to Reflector links does not pass originating ISSI
- **Not recommended to use:**
 - Too many transcoding (ACELP <--> analog <--> OPUS <--> ACELP)
 - Poor quality of analog audio on many SVXLink nodes

Asterisk PBX

chan_transit.so

- **chan_transit.so** – our own Asterisk module, implements TetraPack's Transit IPC protocol (should run on the same host as TetraPack Core)
- **codec_pack.so** – our own port of TETRA codecs to Asterisk (ACELP, ...)
- **Possibilities**
 - Individual simplex calls with PTT control (RADIO_KEY/RADIO_UNKEY)
 - Duplex individual, PSTN or PBX calls
 - TETRA codec selection / DTMF pass
 - TETRA call priority management
 - Short messaging (out-of-band messaging)
- **Use-cases**
 - Ham telephony
 - Direct call to emergency services
 - AllStarLink access (in theory)

Supported radio access technologies

- **motorola compactTETRA (CTS)**
 - Designed by DAMM and Frequentis, labeled by Motorola
 - Built-in network controller (BSC)
 - **NOT compatible** with Motorola Dimetra
 - Supported since 2023 with the first release of TetraPack
- **motorola dimetra**
 - Designed and produced by Motorola
 - Support in TetraPack - new for this year
 - Development and testing based on Dimetra R5 and R9
 - **Uses dedicated Dimetra Core system!**




motorola compactTETRA

motorola compactTETRA

In details

- Designed by DAMM and Frequentis, labeled by Motorola
- Uses E1 closed-ring topology
- Up to 8 base-stations
- No need for dedicated network core
- Voice and signaling only over E1
- Proprietary <Inter-site Connect>
- Not compatible to ISI/E1 (TETRA Interconnection standard)
- Base-station controller (BSC411) runs on Windows NT 4.0 Embedded




Dummy

- Client software to connect Motorola CompactTETRA (CTS-X00) zones
- Emulates Base Station and Gateway PC
- Up to 31 mobile and 32 "fixed" calls (maximum capacity of emulated nodes)
- Debian Linux 11+, x86-64 or arm64 (Raspberry Pi 4+)
- Osmocom icE1usb interface for E1
- Extra software – CTS log collector



Motorola CTS-X00 Site



Dummy

In details

- Transmits application-level messages between CTS E1 and TetraPack Core server
- Decodes/encodes full signaling stack:
 - E1 handler \
 - HDLC FSM -- (normally done by IC on BSC411 board)
 - Q.921 FSM /
- Inter-site Connect transport including priority management (normally done by ISCD2.EXE)
- Decodes/encodes E1 and pre-buffers carrier streams (normally done by BSC411/TR412 boards)
- Partially emulates BSS.EXE/GWS.EXE (presence / status updates)
- VTUN over E1 between CTS and host (does not forward to the server)
- Uses the same bssparams.txt configuration file as a base station
- Typical IP bandwidth 4-100 Kbits/sec
(that's nothing in comparison to TDMoIP – 2x 2 Mbits/Sec, 2x 8000 PPS constantly)

Osmocom icE1usb


- Available for ordering, not expensive
- USB to connect to PC
- Role (NE/NT) can be selected by jumpers, can be used with a regular network cable
- User-space Linux driver, no need to change kernel
- Supports required work mode (SUPERCHANNEL)





Dimetra hardware


Base stations



EBTS (gen1, gen2)



MBTS



MTS2/4

Dimetra hardware

Core systems



CP1500 (gen1)



Sun Netra + IBM Power (gen2)



Core X (HP ProLiant)

Dimetra hardware

Core systems

- **Sun CP1500-based**
 - Can run Dimetra up to R6.2
 - Fully hardware
 - Motorola-proprietary cPCI boxes, ZNYX redundant ethernet blades
- **Sun Netra + IBM Power**
 - Standard 19" equipment
 - Solaris 9+ containers
 - Multiple support boxes based on PowerPC / x86 / Linux / Windows
 - Dimetra R6-R8 (?)
- **Core X**
 - HP Proliant DL-series
 - Linux / Linux KVM or VMware / Windows
 - Many virtual machines running on a single box

Dimetra concept

General information

- Centralized switching and network management
- Redundant configuration of core components
- Shares many core components with SmartZone, Astro P25, MOTOTRBO

Capacity Max


- **Pure IPv4-based private (RFC1918) packet-switched transport**
- **EBTS/MBTS base stations use IP over FrameRelay (E1 or X.25)**
- **MTS2/4 base stations use IP over IP VPN**
- Predefined fixed IP plan
- Media and signaling use mostly IP multicast

Our Dimetra Core approach

Base concept

- ZeroTier MP-VPN to connect sites and core
- OSPF for unicast routing, PIM dense-mode for multicast routing
- Two options to connect EBTS/MBTS base stations
 - Cisco router with E1 card + any box (Linux/OpenWRT/Mikrotik) for ZT
 - Osmocom icE1usb + any Linux box for osmo-e1d + fred + FRR + pimdd + ZT
- One option to connect MTS2/4 base stations
 - Any Linux box + FRR + pimdd + ZT

Dimetra Zone



Option 2: FRED

FrameRelay-over-E1

- Our own gateway software to run on on-site E1 connection
- Bridges IPv4/IPv6/Ethernet packets between Linux kernel and FrameRelay over E1 (RFC 2427, RFC 2590)
- Supports FRF.12 (inner and outer) fragmentation for incoming traffic
- Implements basic DCE-PVC LMI with support of ITU-T Q.933-A, ANSI T1.617-D, GOF (automatic detection)
- Acts via TUN/TAP network interfaces (one per DLCI) on Linux side
- Can share icE1usb interface with another FRED / dummy / etc
- Debian 12 arm64 or amd64, tested on Raspberry Pi CM4, Raspberry Pi 5

TetraPack Sidecar

- Agent software to connect Dimetra Core (on per-zone basis) with TetraPack Core (like TetraPack Dummy for CompactTETRA)
- Should run close to Dimetra Core in the same private network
- Single TCP connection to TetraPack Core over Internet
- Emulates EBTS TSC to register users and to pass calls
- Watches for signaling between TSCs of real base stations and Zone Controller to grab registrations, group affiliations and group calls

```
TetraPack Sidecar 20240123-142211  
Copyright 2023-2024 Artem Prilutskiy
```

```
2024-01-24 18:33:44.895 [i] Started  
2024-01-24 18:33:46.897 [✓] Connecting to Zone Controller...  
2024-01-24 18:33:46.992 [🟡] Zone Controller link #1 status change: GRANT  
2024-01-24 18:33:46.994 [🟢] Zone Controller link #1 status change: ACTIVE  
2024-01-24 18:33:46.997 [🟡] Zone Controller link #2 status change: GRANT  
2024-01-24 18:33:46.997 [🟢] Zone Controller link #2 status change: GRANT  
2024-01-24 18:33:47.000 [🟡] Zone Controller link #1 status change: ACTIVE  
2024-01-24 18:33:47.004 [🟡] Zone Controller link #2 status change: GRANT  
2024-01-24 18:33:47.004 [🟡] Zone Controller link #2 status change: GRANT
```





TETRAPACK

User Experience

DMR <-> TETRA

Individual calls

- TETRA -> DMR: DOUBLE PTT (TO SETUP A CALL AND THEN TO TRANSMIT)
- Recommended settings:
 - **PTT Call Back Timer – Disabled**
(respond for initial delay on call DMR->TETRA)
 - **Hook Method for Outgoing Simplex Individual Call – Direct**
(respond only for transmitted call capabilities, the bridge is tolerant to this setting)
 - **Preferred Hook Method for Incoming Simplex Individual Call – Direct**
(allows TETRA radio to hook a call automatically - DMR side doesn't know about when the call hooked)



Emergency Options		
TMO Voice Services		
Pre-emptive Priority Call		
Scanning Parameters		
Voice Services Options		
Announcement Call		
DMO Parameters		
13	PTT Call Back Timer, msec	3000
▶ 14	PTT Call Back Timer Enabled	<input type="checkbox"/>
15	PTT during Received Group Call	<input type="checkbox"/>
16	Hook Method for Outgoing Simplex Individual Call	Direct
17	Preferred Hook Method for Incoming Simplex Individual Call	Direct
18	Hook Method for Outgoing Duplex Private Call	Hook

Links

- <https://tetrapack.online/>
- <https://t.me/TetraPackGeneralSupport>

